



CE PROVING





Control of the following functions :

- ✓ Preblocking
- ✓ Blocking
- ✓ Proving
- ✓ End of Proving
- ✓ Holding
- ✓ Lighting (option)
- ✓ 9 possible registered programs :
 - * 1 Program «Direct cold»
 - * 1 Program «Direct proving»
 - * 8 programmables recipes



577, rue Célestin Hennion
59144 Gommegnies - France
Tel : (33) 03 27 28 18 18
Fax : (33) 03 27 49 80 41
<http://www.eurofours.com>
email:infos@eurofours.com

PROGRAMMING INSTRUCTIONS : PFRD-F00R003-GB

Pictures are not contractual.
The company reserves the right to change specifications without notice - Copying forbidden


SUMMARY

PRESENTATION OF THE CONTROL PANEL	p.3
ACCESS LEVEL	p.4
FERMENTATION CYCLE CURVE : SETTING RANGES	p.5
USER MENU - ACCESS TO THE PARAMETERS	p.6
Adjustment of recipes	p.7
Date and Time adjustments	p.10
Setting of the regulator parameters	p.11
DOWNLOAD AND UPLOAD OF THE RECIPES THROUGH THE USB STICK	p.12
Download of the programs from the control board	p.12
View of the programs file on a computer	p.13
Upload of the programs in the control board	p.14

The company reserves the right to change specifications without notice - Copying forbidden

PRESENTATION OF THE CONTROL PANEL

Take time to read the manual to familiarize yourself with the use of the appliance.



ACCESS LEVEL



The ability to modify the settings is governed by the authorization



level :





No single setting can be modified. The only active keys are :

Control board starting-up  - Control board stop 

✓ Cycle starting  - Cycle stopping 

✓ Lighting  

✓ Manual control of defrosting 

✓ Selection of the recipes : Direct cold 

✗ Direct cold

✗ Direct proofing

✗ 8 Programs



Selection and **TEMPORARY** modification of the program in progress « Direct cold » + « Direct proofing ».



Selection and **TEMPORARY** modification of the program in progress : All the programs.
Access to the programming of : «Direct cold » + «Direct proofing».



All the programs :
Selection and **TEMPORARY** modification of the program in progress.

Access to the programming .



* Look at the paragraph : «Fast modification of the cycle in progress».- USE INSTRUCTIONS

FERMENTATION CYCLE CURVE : SETTING RANGES

Preblocking




Temperature : adjustable from -7°C to 5°C

Phase duration : adjustable from 00:00 to 06:00

The set temperature must be reached before the loading of products. When set temperature is reached, the buzzer rings for 30 seconds and the display indicates that loading of products has to be done. From this moment, the countdown of the phase is starting.


Blocking



Temperature : adjustable from -7°C to 5°C

Phase duration : not adjustable

Proving



Temperature :

- ✓ 7°C to 35°C (Standard)
- ✓ 7°C to 40°C (on request)
- ✓ 7°C to 45°C (on request)

Phase duration : adjustable from 00:00 to 23:50

Hygrometry :

- ✓ Without steam generator : adjustable from 45% to 95%
- ✓ With steam generator : 45% to 100%

End of Proving



Day of cycle end :
maxi 3 Days

Cycle end time : adjustable from 00:00 to 23:50

Holding




Temperature :


- ✓ 3°C to 35°C (Standard)
- ✓ 3°C to 40°C (on request)
- ✓ 3°C to 45°C (on request)

USER MENU - ACCESS TO THE PARAMETERS


When a cycle is in progress, the programming access is locked.



Adjustment of recipes



Date and Time adjustments



Setting of the regulator parameters



Adjustment of recipes




10 possible registered programs :


- ✓ 1 Direct cold
- ✓ 1 Direct proofing
- ✓ 8 adaptable programs



The name of both specific programs «Direct cold» and «Direct proofing» is changeless.




The program name can be composed with letters, numbers and special characters.
 Number of characters available : 21



The name of specific programs is changeless.

Creation / Modification of a program

Preblocking




Caution : here, 2 touch areas (hours : minutes)

Press the parameter to be adjusted




Key in the new value and register by pressing «ENTER»




To reach the other phases, press the corresponding curve part.


Blocking




Proving



End of Proving




Holding




Do not forget to press the floppy disk icon to register the modification(s) done in the programs.

Date and Time adjustments



Next page



DD / MM / YY

31/03/2013



MM / DD / YY

03/31/2013




Date

Press on each zone to be modified.

Hour

Day (Automatically calculated in function of the date)



Press the floppy disk icon to register.

Date and time are updated in the gray band



CAUTION


In the countries applying summer time and winter time, do not forget to modify the hour (the function is not automatic).

Setting of the regulator parameters



Next page

Translations file version



Language


Access level

Beep keys

Brightness of the screen : adjustable from 50 to 100%

Screensaver : adjustable from 0 to 30 mn

Language :



Access level :



Beep keys :



DOWNLOAD AND UPLOAD OF THE RECIPES THROUGH THE USB STICK


Download of the programs from the control board



Take a empty USB FAT32 formatted drive.

BEFORE


View of the USB stick content on a computer




Control board starting-up by pressing the key.



Proving




The transfer begins as soon as the USB stick is plugged.



Wait until viewing of the green icon and the ringing of the buzzer before removing the USB stick.

AFTER


View of the USB stick content on a computer



The file «FRPRG_A0» contains the list of programs to be uploaded into the control board.

The file «FRPRG_A1» is only used for the double cabinets but must nevertheless be present whatever the machine.

View of the programs file on a computer



Upload of the programs in the control board

Installer menu :
Check the access
level



IMPERATIVE



If the access level is adjusted on «0, 1, 2», the control board will not detect the USB stick.



BEFORE

Viewing of existing recipes
before injection of new recipes
file.



Nom	Modifié le	Type	Taille
FRPRG_A0	20/08/2013 17:08	Document texte	212 Ko
FRPRG_A1	20/08/2013 17:08	Document texte	212 Ko


The files «FRPRG_A0 + FRPRG_A1» contain the list of programs to be uploaded into the control board.



Proving



The transfer begins as soon as the USB stick is plugged.




Wait until viewing of the green icon and the ringing of the buzzer before removing the USB stick.



Viewing of the new recipes file (FRPRG_A0)

AFTER



Before replacing both programs files from the control board by the new files «FRPRG_A0» + «FRPRG_A1» from the USB key, a copy of the original files is automatically recorded on the key as «FRPRG_A0.OLD» + «FRPRG_A1.OLD».